

DESCRIPTION	CATALOGUE NUMBER	STD PK	CTN QTY	LIST PRICE
-------------	------------------	--------	---------	------------

Flush Switches

1 Gang

10A 1 Gang 1-Way Switch

ESM31/1/2A

10A 1 Gang 2-Way Switch

ESM31/2/3A

2 Gang

10A 2 Gang 1-Way Switch

ESM32/1/2A

10A 2 Gang 2-Way Switch

ESM32/2/3A

3 Gang

10A 3 Gang 1-Way Switch

ESM33/1/2A

10A 3 Gang 2-Way Switch

ESM33/2/3A

4 Gang

10A 4 Gang 1-Way Switch

ESM34/1/2A

10A 4 Gang 2-Way Switch

ESM34/2/3A

Bell Switches

10A 1 Gang Bell Push Switch with Bell Symbol

ESM31BPA

10A 1 Gang Bell Push Switch Marked "Press"

ESM31/BPRPA

10A 1 Gang Bell Push Switch Marked "Press"

ESM31BPRA/P

10A 2 Gang Push Button Switch with Red/Green Dolly

ESM32BPA

10A 3 Gang Push Button Switch with Neon

ESM33BPAN

Single/Double Pole Switches

Single Pole Switches

20A 1 Gang 2-Way Single Pole Switch

ESM31/20A

20A 2 Gang 2-Way Single Pole Switch with Neon

ESM32/20NA

Double Pole Switches

20A 1 Gang Double Pole Switch

ESM31D20A

20A 2 Gang Double Pole Switch with Neon

ESM32D20NA



ESM31/1/2A



ESM32/1/2A



ESM33/1/2A



ESM34/1/2A



ESM31D20A



ESM32D20NA